



## Clean-Up Room, 7m2

Room Code	CLUP-7
Briefed Area	7.00 m <sup>2</sup>
Ceiling Height	2.7 m
Occupancy	1-2 staff
Hours of Operation	Up to 24 hours (dependent on unit operating hours)

**Description** | The Clean-Up Room is used for holding of used trolleys and articles from a procedure Room or catheter laboratory. Items may be sorted, rinsed or disposed of and dispatched to waste holding/ sterilising areas as appropriate.

<b>Electrical</b>	PROTECTION: body protected	<input type="checkbox"/>	<b>HVAC</b>	AIRCONDITIONING: general	<input checked="" type="checkbox"/>
	PROTECTION: cardiac protected	<input type="checkbox"/>		AIRCONDITIONING: HEPA filtered	<input type="checkbox"/>
<b>Lighting</b>	LIGHTING: general	<input checked="" type="checkbox"/>	AIRCONDITIONING: positive pressure	<input type="checkbox"/>	
	LIGHTING: colour corrected	<input type="checkbox"/>	AIRCONDITIONING: negative pressure	<input type="checkbox"/>	
	LIGHTING: dimmable	<input type="checkbox"/>	VENTILATION: exhaust	<input checked="" type="checkbox"/>	
	LIGHTING: indirect	<input type="checkbox"/>	VENTILATION: natural	<input type="checkbox"/>	
<b>Nurse Call and Duress</b>	NURSE CALL SYSTEM: buttons / handset	<input type="checkbox"/>			

**Additional Considerations**

### Doors and Windows

CODE	DESCRIPTION	COMMENT
DOHI-013.01	DOOR: hinged, 1 leaf, 900 clear opening, solid, standard vision panel	[DWGL-005]
AFDPR-006.01	DOOR PROTECTION: plate, to 900H	[DWPR-005] to corridor side, extent dependent on movement of beds and mobile equipment in adjacent area; to be coordinated with corridor wall protection
AFDPR-006.01	DOOR PROTECTION: plate, to 900H	[DWPR-005] to room side
AFDPR-056.03	DOOR FRAME PROTECTION: full wrap, to 1200H	[DWPR-010] optional, provision and extent dependent on frame material/finish and movement of beds and mobile equipment in adjacent area

### Finishes

CODE	DESCRIPTION	COMMENT
FLVY-112	FLOOR FINISH: vinyl, seamless, non-slip, safety	[FLVY-004]
FLSK-021	SKIRTING: vinyl, integral with floor vinyl, coved	[FLSK-010]
WLFI-002	WALL FINISH: paint, clinical areas	[WLWA-005]
WLFI-011.05	WALL FINISH: vinyl, to 1800 AFFL	[WLWA-021]
CLFS-013	CEILING: flush set, suspended, moisture resistant	[CLFS-009]
CLFI-002	CEILING FINISH: paint, clinical areas	[CLFS-009]

CODE	DESCRIPTION	COMMENT
CLCN-031	CORNICE: square set	[CLCN-008]



## Joinery

CODE	DESCRIPTION	GROUP	QTY	COMMENT
JOBE-033	BENCH: 600D, stainless steel lipped	①	1	[FIJO-021] with wet edge
JOBE-231	BENCH SUPPORT: legs and frame, stainless steel	①	1	[FIJO-100]
JOBE-232	BENCH SUPPORT: legs and frame, stainless steel, with low shelf	①	1	[FIJO-196] + [FIJO-197]



## Fittings, Furniture and Equipment (FF&E)

CODE	DESCRIPTION	GROUP	QTY	COMMENT
FIDI-106	DISPENSER: PPE, disposable gloves, wall mounted	②	1	[FIDI-014]
FIDI-231	DISPENSER: paper towel, wall mounted	②	1	[FIDI-025] to basin
FIDI-256	DISPENSER: soap, wall mounted	②	1	[FIDI-030] to basin
FIDI-261	DISPENSER: soap, antimicrobial, wall mounted	②	1	[FIDI-031]
FIHR-111	BRACKET: sharps bin, wall mounted	②	1	[FIHR-016]
FQCL-211	LINEN CARRIER: dirty, single skip	③	1	[MMGE-048]
FQWS-003	BIN: sharps, clinical, medium	③	1	[FQCW-044]
FQWS-051	BIN: general waste, 20L	③	1	[FQCW-016]
FQWS-098	BIN: recycling, paper/cardboard, 240L	③	1	[FQCW-029] optional
FQWS-233	BIN: clinical waste, 50L	③	1	[FQCW-008]
FQWS-253	BIN: cytotoxic waste, 50L	③	1	[FQCW-060] optional
HYBA-121	BASIN: type B, handwashing	①	1	[HYBA-010] elbow action levers
HYBA-301	SINK: single bowl	①	1	[HYBA-052] hot water
HYTP-062	TAPWARE: basin, tap set, fixture mounted, lever handles	①	1	[HYTP-038]
HYTP-067	TAPWARE: basin, tap set, wall mounted, lever handles	①	1	[HYTP-037] 1 to sink, 1 to basin
MMTR-004.02	TROLLEY: stainless steel, 900W x 490D x 900H nom, 2 tier	③	1	[FQSM-016]



## Major Medical Equipment (MME)

CODE	DESCRIPTION	GROUP	QTY	COMMENT
MMIC-351	DISINFECTOR: ultrasound probes, freestanding	②	1	[MMIC-122] optional



## Engineering Services

CODE	DESCRIPTION	GROUP	QTY	COMMENT
ELGP-201	GPO: double, wall mounted	①	1	[ELGP-208]
ELSW-001	SWITCH: light	①	1	[ELBO-015]
HYDR-021	DRAIN: floor waste, round	①	1	[HYDR-004]

For guidance on how to use the Room Data Sheet, please visit the [AushFG website](https://www.aushfg.com.au).