



| Room Name | After Hours Blood Fridge | Room Number AHBF | | | | |
|------------------------------------|---|---|--|--|--|--|
| Revision | 4 | | | | | |
| Issue Date | 24.06.2022 | | | | | |
| BRIEFING | | | | | | |
| Briefed Area | 8.00 m ² | | | | | |
| Hours of Operation | Available 24 Hours | | | | | |
| Occupancy | 1-2 staff, intermittently | | | | | |
| Acoustics | | | | | | |
| Remarks | | | | | | |
| Description / Special Requirements | The After Hours Blood Fridge is a discreet area for refrigerated storage of blood and blood products for access by authorised personnel after hours where a 24 hour pathology service is not available. This room is typically located on the periphery of a Pathology unit and may have direct, secure access to the Pathology laboratory with ready access to the transfusion service area. | | | | | |
| | Additional Considerations: | | | | | |
| | Refrigerator temperature monitoring is required and is to be connected to the building management system (BMS). The alarm is to provide alerts where 24-hour monitoring is undertaken, within the unit and/or remotely. Temperature monitoring is to meet ANZSBT guidelines. | | | | | |
| | | ezers or lockable sections within the after hours fridge may be Pathology laboratory workflows. | | | | |
| | | dges for blood product tracking and other ICT requirements will blicies and service requirements. | | | | |
| | Door width to allow for installation of fridge, including considerations for future proofing as equipment is replaced. | | | | | |
| SERVICES | | | | | | |
| Electrical | BODY PROTECTED | CARDIAC PROTECTED | | | | |
| HVAC | AIRCONDITIONING | AIRCONDITIONING: hepa filtered | | | | |
| | AIRCONDITIONING: positive pressure | AIRCONDITIONING: negative pressure | | | | |
| | EXHAUST: room exhaust | VENTILATION | | | | |
| Lighting | LIGHTING: colour corrected | LIGHTING: dimmable | | | | |
| | LIGHTING: downlights | LIGHTING: downlights, dimmable | | | | |
| | LIGHTING: fluorescent/LED, downlights | LIGHTING: fluorescent/LED, flush with ceiling, tamper proof | | | | |
| | LIGHTING: fluorescent/LED, general | LIGHTING: indirect | | | | |
| Security / Nurse Call | NURSE CALL SYSTEM | | | | | |

Room Fabrics







Room Name

After Hours Blood Fridge

Room Number AHBF

| AusHFG code | Description | Comment |
|-------------|---|-------------------------------------|
| CLTI-008 | CEILING: plasterboard, drop-in tiles, prefinished, 600 x 1200 | |
| CLCN-009 | CORNICE: wall trim fixing | |
| DWSC-021 | DOOR: 1400mm c/o, 1 1/2 leaf, solid core, paint | |
| DWSC-003 | DOOR: 910mm c/o, single leaf, solid core, paint | optional, to laboratory if adjacent |
| DWPR-005 | DOOR PROTECTION: protection plate to 900 AFFL | |
| FLVY-007 | FLOOR FINISH: vinyl, seamless, coved, standard slip resistant | |
| FLSK-010 | SKIRTING: vinyl, floor vinyl coved, 150H, prefinished | |
| WLWA-004 | WALL FINISH: paint, acrylic, washable | |

Fittings, Furniture and Equipment (FF&E) Items

| AusHFG code | Description | Group | Qty | Comment |
|-------------|--|-------|-----|--|
| ITNE-003 | BAR CODING: reader | 3 | 1 | |
| FIJO-017 | BENCH: 600D, open under | 1 | 1 | laboratory grade |
| ITNE-007 | COMPUTER: desktop, with display screen | 3 | 1 | |
| FIDI-001 | DISPENSER: alcohol based hand rub | 2 | 1 | |
| MMLA-053 | FRIDGE: blood products, single door | 3 | 1 | sections may be lockable; BMS monitored, audible alarm 24hr; size is to suit service requirements |
| FIJO-213 | PANEL: joinery carcass end | 1 | 1 | |

Engineering Services

| AusHFG code | Description | Group | Qty | Comment |
|-------------|--|-------|-----|--|
| ITBU-001 | ALARM: equipment monitoring, temperature | 1 | 1 | may be integral to fridge |
| ELGP-208 | GPO: double, wall mounted | 1 | 2 | |
| ELGP-123 | GPO: emergency power, single, wall mounted | 1 | 1 | to fridge |
| ITIN-026 | OUTLET: data, double RJ45, wall mounted | 1 | 1 | |
| ITIN-016 | OUTLET: data, single RJ45, wall mounted | 1 | 1 | to fridge for temperature monitoring |
| ITSE-038 | READER: access control, general | 1 | 2 | 1 to entry, 1 is optional to laboratory door if provided |
| ELBO-015 | SWITCH: light, single | 1 | 1 | |

Page: 2 Print Date: 29/06/2022